


ŠEME VEZIVANJA
WIRING DIAGRAMS




72101

Sklopka jednopolna
1 way switch


72111

Taster sklopka jednopolna
Push-button switch




72103

Sklopka naizmienična
2 way switch




72104

Sklopka ukrсна u kombinaciji sa dve sklopke naizmienične
Intermediate switch in combination with two 2 way switches




72105

Sklopka jednopolna sa priključkom za nulti provodnik (indikatorska)
1 way switch with connection for the neutral conductor (with indikator)




72106

Sklopka dvopolna
2 pole switch




72114

Taster sklopka za roletne
Push-button shutters switch




72201

Elektronski regulator
Dimmer rotative




72202

Elektronski regulator sa naizmieničnom sklopkom
Dimmer with alternative switch




Elektronski regulator sa naizmieničnom sklopkom, povezivanje u naizmieničnom režimu rada
Dimmer with alternative switch, wired in alternating mode




72204

Elektronski regulator za induktivno opterećenje
Dimmer for inductive load




Elektronski regulator za induktivno opterećenje, povezivanje u naizmieničnom režimu rada

Dimmer inductive load, wired in alternating mode




72205

Elektronski regulator za LED
Dimmer for LED




Elektronski regulator za LED u režimu rada sa nultim provodnikom
Dimmer for LED with neutral conductor mode



72203

Infracrveni detektor pokreta
Infrared motion detector

Dodatni tasteri za ručno aktiviranje
Additional buttons to manually activate



74283

Priključnica USB punjač
Power supply unit USB